

## CONTROL UNIT LET-OFF SOLEX 297 E



Solution for easy warp let-off

CREALET AG Alte Schmerikonerstrasse 3 8733 Eschenbach/SG Switzerland Tel. +41 (0) 55 286 30 20 Fax +41 (0) 55 286 30 29 E-Mail info@crealet.com

www.crealet.com

### **OVERVIEW**

The SOLEX let-off controller optimizes the weaving procedure and simplifies operation.

It also has a particular influence on the fabric quality and contributes to a regular weave structure.

The controller is designed for applying warp tension control to weaving machines and comes by default without a driver.

It only provides an analog-output motor speed of 0-10VDC for the external driver.

There are no unnecessary functions and no keys. It is a lean-design, cost-effective solution for easy warp let-off.

## **KEY ADVANTAGES**

- simple handling
- maintenance-free
- very cost-effective
- higher fabric quality



# LINEAR PROXIMITY SENSOR

The SOLEX let-off controller is designed primarily for small warp beams that are used for narrow weaving ma-chines, selvedge let-offs and for sectional warp beams for fancy fabrics or industrial technical yarns that have to be partially woven into the fabric. Depending on the application, various motor drivers and sizes are available that supply the necessary warp thread to the weaving machine and maintain the yarn tension at a constant level from full to empty beam. The warp thread tension is measured by a linear proximity sensor fitted to the back rest roller.

#### SLOW MOTION MODE

In slow motion mode the let-off moves as much as the back rest roller stays in its reference setting.



# CREALET AG

#### WEAVING MODE

As soon as a machine run signal between 10-48 VAC/DC is available, the control system is in weaving mode. During this process the let-off will keep the position of the back rest roller at its reference setting and thus main-tain the warp thread tension at a constant level. The position of the back rest roller is measured by a linear proximity sensor. If the weaving machine run signal is set back, the let off stops and moves the back rest roller slowly to its reference setting and optimal starting position.